

FMR Series Upgrade Instructions

- 1) Download the Software Package from: <http://www.intelleflex.com/Support.Downloads.asp>
- 2) Unzip the Reader Upgrader to your desktop.
- 3) Run the setup.exe application to install the upgrader on your machine.
- 4) If you do not have .NET client installed, follow the instructions to install .NET Framework 4.
- 5) Follow the instructions to install the upgrader.
- 6) If the application does not launch automatically, please launch it by navigating to:
Start > All Programs > Intelleflex > Reader Upgrader
- 7) There are two upgrade files included with the FMR upgrade package in the original downloaded folder. One package is included for the FMR-5000 (if supported), and one for FMR-6000. In the Reader Upgrader application, select the appropriate file for the reader(s) you plan to upgrade by clicking the Browse... button. You can only upgrade one type at a time.
- 8) Then select the reader(s) to upgrade in the list. If a reader does not appear, you will need to enter the IP address manually by clicking the *Add* button.
- 9) After verifying the correct package and readers are selected in the Reader Upgrader application, click the *Upgrade* button and the program will begin the upgrade process.

Supported Platforms

- Windows 7 (x32/x64)
- Windows XP (x32) Service Pack 3 or greater

Technical Support

Please submit a support request at: <http://www.intelleflex.com/Support.asp>